


ref.3011352


WALL MOUNT BRACKET FOR BLOWERS 3008300-3008301-3008302-3008303

KIT CONTENTS


- 2 wall plugs
- 1 strap with threaded rod and clasp



Hole for the threaded rod located at one end of the strap.




2 holes to insert the wall plugs and fix the bracket to the wall.



1. PREPARE THE STRAP

- Position the strap before fixing the bracket to the wall. The blower will be placed on the bracket in this way. Therefore, fix the bracket to the wall before installing the blower.



2. MARK THE HOLES

- Place the bracket on the wall at the desired location.
- Mark the position of the two mounting holes.

3. INSERT THE WALL PLUGS


- Drill two holes at the marked positions using a drill bit suitable for the wall.
- Insert the 2 wall plugs into the holes.

4. FIX THE BRACKET TO THE WALL

- Position the bracket on the wall, aligning the holes with the plugs.

5. PLACE THE BLOWER

- Once the bracket is securely mounted to the wall, place the blower.
- Insert the rubber feet of the blower into the holes provided. There is only one correct mounting orientation for the blower.



6. SECURE THE STRAP

- Position the strap around the blower by passing it through the inside of the handle.
- Close the buckle (latch).
- Then tighten the screw to tighten the strap as much as possible.

IMPORTANT

Make sure the bracket is securely fixed to the wall and the strap is properly tightened before each use of the blower.

SAFE USE

The blower must be properly supported by the strap and correctly positioned on the bracket to ensure safe use at all times.